

Plug it in. Enjoy!





Press the button to increment all LED intensities by 20%.

(Only applies to Vega lights that are not currently associated with a controller.)



Press and hold the button for 3 seconds to start demo mode. Press and hold to end.



Press and hold the button for 7 seconds to reset the Vega to its factory default settings.

---

## Maintenance

---

Do not lay objects on top of the Vega, controller or power supply.

Inspect the Vega regularly.

Unplug the Vega when cleaning to prevent any shock hazards.

Wipe Vega with damp cloth once a week. DO NOT use ammonia-based cleaners. Avoid the power plug area. A can of compressed air may be used to blow dust out of the heat sink.

Do not allow liquids to pool on top of or inside the Vega. The Vega is not waterproof. Do not submerge in water, saltwater, or other solutions.

For instructional videos, FAQs and support, visit:

[support.aquillumination.com](http://support.aquillumination.com)

The device contains:  
C2 Development, Inc's Wireless Module  
Part Number: 3003-0003  
FCC ID: ZOM-30000003  
IC: 9795A-30000003

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation of the device. Any changes or modifications not expressly approved by C2 Development, Inc. could void the user's authority to operate this equipment, and/or the product that incorporates the equipment.

© C2 Development Inc, 2012